

SWAROVSKI ETERNAL 011101A Single Lever Basin Mixer

INSTALLATION INSTRUCTION SINGLE LEVER WASH BASIN MIXER


XACCESSORIES CHECKING

LIST OF THE STANDARD ACCESSORIES:

Please double-check the accessory list hereinafter and contact our company or our distributor for any unconformity.

Remarks:


- 1. Without affecting their performancing, accessories may be changed without further notice;
- 2.Drawings for reference only, product size & shape refer to actual.





Accessories list		
No.	Name	Qty
1	Handle	1
2	Screw	1
3	Index	1
4	Dome	1
5	O-ring	1
6	Nut	1
7	Cartridge	1
8	Main body	1
9	Aerator assembly	1
10	O-ring	1
11	Fixed assembly	1
12	Inlet hose	2


Installation Instructions


- ☆ Do not disassemble the main body, as it has been installed & commissioned correctly & precisely before leaving the factory;
- ☆ To avoid the faucet from jamming, do flush the water pipe before installation;
- ☆ After installation, make sure every joint safely sealed & no leaking;
- ☆ Using condition: Working pressure at 0.05-1.0MPa(including cold & hot water pressure), with applicable water temperature: 4°C-90°C;
- Make sure to connect the hot/cold inlet pipe correctly, if standing in front, hot water pipe connecting to the left & cold water pipe connecting to the right.















%Usage

☆How to operate the handle

1.Raise the handle up for opening water, push it down for close; 2.Turn the handle to the left to increase hot water flow for higher

2. Turn the handle to the left to increase hot water flow for higher water temperature, and lower water temperature by operating reversely.



Cleaning & Maintenance

- ☆ To keep the product clean & shining, follow as below:
 - 1.Flush with clean water & dry with soft cloth only;
 - 2. If any dirt, clean with soft liquid or transparent glass detergent;
 - 3.Do not use any scrubbing detergent, polisher, sane-cloth, paper tissue or scraper;
 - 4.Do not use acid detergent, insoluble grain-like detergent or soap;
 - 5.Circumrotate the aerator off and clean it when necessary.

