INSTALLATION INSTRUCTION


XACCESSORIES CHECKING

LIST OF THE STANDARD ACCESSORIES:

Please double-check the accessory list hereinafter and contact our company or our distributor for any unconformity.

Remarks:


- 1. Without affecting their performancing, accessories may be changed without further notice;
- 2.Drawings for reference only, product size & shape refer to actual.




| Accessories list | | |
|------------------|----------------------|-----|
| No. | Name | Qty |
| 1 | Main body A | 1 |
| 2 | Connector | 3 |
| 3 | Plate | 1 |
| 4 5 | Screw | 6 |
| 5 | Shower head | 1 |
| 6 | Main body B | 1 |
| 7 | Plate | 1 |
| 8 | Connector | 1 |
| 9 | Shower holder | 1 |
| 10 | Hand shower | 1 |
| 11 | Divertor handle | 3 |
| 12 | Shower flexible hose | 1 |
| 13 | Spout | 1 |
| 14 | Connector | 1 |
| 15 | Handle | 1 |
| 16 | Screw | 4 |
| 17 | Index | 4 |


Installation Instructions


- ☆ Do not disassemble the main body, as it has been installed & commissioned correctly & precisely before leaving the factory;
- ☆ To avoid the faucet from jamming, do flush the water pipe before installation;
- ☆ After installation, make sure every joint safely sealed & no leaking;
- ☆ Using condition: Working pressure at 0.05-1.0MPa(including cold & hot water pressure), with applicable water temperature: 4°C-90°C;
- ☆ Make sure to connect the hot/cold inlet pipe correctly, if standing in front, hot water pipe connecting to the left & cold water pipe connecting to the right.








X Installation Procedures

























XUsage

☆How to operate the handle





※ Cleaning & Maintenance

- ☆ To keep the product clean & shining, follow as below:
 - 1.Flush with clean water & dry with soft cloth only;
 - 2.If any dirt, clean with soft liquid or transparent glass detergent;
 - 3.Do not use any scrubbing detergent, polisher, sane-cloth, paper tissue or scraper;
 - 4.Do not use acid detergent, insoluble grain-like detergent or soap;
 - 5. Circumrotate the aerator o ffand clean it when necessary.

