

INSTALLATION INSTRUCTION


※ ACCESSORIES CHECKING

LIST OF THE STANDARD ACCESSORIES:


Please double-check the accessory list hereinafter and contact our company or our distributor for any unconformity.

Remarks:

1. Without affecting their performing, accessories may be changed without further notice;
2. Drawings for reference only, product size & shape refer to actual.





Accessories list		
No.	Name	Qty
1	Main body	1
2	Plate	1
3	Screw	2
4	Allen key	1
5	Connector	1
6	Screw	2
7	Shower flexible hose	1
8	Shower holder	1
9	Hand shower	1
10	Handle	1
11	Divertor knob	1
12	Top shower head	1
13	Shower arm	1




※ Installation Instructions

- ☆ Do not disassemble the main body, as it has been installed & commissioned correctly & precisely before leaving the factory;
- ☆ To avoid the faucet from jamming, do flush the water pipe before installation;
- ☆ After installation, make sure every joint safely sealed & no leaking;
- ☆ Using condition: Working pressure at 0.05-1.0MPa (including cold & hot water pressure), with applicable water temperature: 4°C-90°C;
- ☆ Make sure to connect the hot/cold inlet pipe correctly, if standing in front, hot water pipe connecting to the left & cold water pipe connecting to the right.



✕Installation




First dig the pipeline according to the above pipeline connection diagram.

After putting the main body into the pre-embedded groove, install the plate, diverter knob, and handle, and tighten them with a hexagonal key.

Wrap the joint thread of the shower socket with thread seal tape and tighten it.

Wrap the thread of the shower arm with thread seal tape, install and tighten the rest of the accessories according to the schematic diagram.

✕Usage



✕ Cleaning & Maintenance

☆ To keep the product clean & shining, follow as below:

- 1.Flush with clean water & dry with soft cloth only;
- 2.If any dirt, clean with soft liquid or transparent glass detergent;
- 3.Do not use any scrubbing detergent, polisher, sane-cloth, paper tissue or scraper;
- 4.Do not use acid detergent, insoluble grain-like detergent or soap;
- 5.Circumrotate the aerator o fffand clean it when necessary.

