

OSLO 72 4701 Concealed Wall Mount Shower Set Combination

INSTALLATION INSTRUCTION


※ ACCESSORIES CHECKING

LIST OF THE STANDARD ACCESSORIES:


Please double-check the accessory list hereinafter and contact our company or our distributor for any unconformity.

Remarks:

1. Without affecting their performing, accessories may be changed without further notice;
2. Drawings for reference only, product size & shape refer to actual.





Accessories list		
No.	Name	Qty
1	Flange	1
2	Shower arm	1
3	Rubber flat mat	1
4	Shower holder	1
5	Main body	1
6	Plate	1
7	Divertor knob	1
8	Screw	2
9	Index	1
10	Handle	1
11	Index	1
12	Allen key	1
13	Hand shower	1
14	Rubber flat mat	1
15	Shower holder	1
16	Shower flexible hose	1
17	Wall outlet	1
18	Thread seal tape	1




※ Installation Instructions

- ☆ Do not disassemble the main body, as it has been installed & commissioned correctly & precisely before leaving the factory;
- ☆ To avoid the faucet from jamming, do flush the water pipe before installation;
- ☆ After installation, make sure every joint safely sealed & no leaking;
- ☆ Using condition: Working pressure at 0.05-1.0MPa(including cold & hot water pressure), with applicable water temperature: 4°C-90°C;
- ☆ Make sure to connect the hot/cold inlet pipe correctly, if standing in front, hot water pipe connecting to the left & cold water pipe connecting to the right.



※ Installation Procedures





※ Usage

☆ How to operate the handle

1. Raise the handle up for opening water, push it down for close;
2. Turn the handle to the left to increase hot water flow for higher water temperature, and lower water temperature by operating reversely.

☆ How to operate the Divertor knob



※ Cleaning & Maintenance

☆ To keep the product clean & shining, follow as below:

1. Flush with clean water & dry with soft cloth only;
2. If any dirt, clean with soft liquid or transparent glass detergent;
3. Do not use any scrubbing detergent, polisher, sane-cloth, paper tissue or scraper;
4. Do not use acid detergent, insoluble grain-like detergent or soap;
5. Circumrotate the aerator off and clean it when necessary.

